


MAS-503-PLUS 英文操作说明书V1.2(欧规) 145x105mm 24.05.03

Warranty

- 1.The warranty period is 12 months from the date of purchase. If it is damaged or malfunctioned during normal use, a new replacement will be provided for free within one year.
- 2.The following conditions need to be paid for repair even during the warranty period:
- (a)Failure and damage caused by misuses or carelessness;
- (b)Damage due to shipping;
- (c)Damage caused by pets(scratches,bites,touching the body or riding products);
- (d)Damage caused by fire, earthquake,and other natural disasters;
- (e)Damage caused during use other than general household use(Long-term use for business, etc.);
3. If you have any problems when the product needs to be replaced or repaired, please contact us through Amazon find your order for our products. We will answer and solve questions for you professionally within 24 hours.

14

Pet Grooming Kit and Vacuum



User Guide

- Safety information 01-02
- Package details 03
- User introduction 04-08
- Daily Care 09-12
- Specification 13
- Warranty 14

Specifications


Wattage:	300W
Voltage:	AC220~240V
Hose length;	1.4M/4.6ft
Suction:	> 10KPA
Dust Cup Capacity:	2.5L
Product Size:	337*152*208mm / 13.3*6*8.2inch
Wire Length:	2.5M / 98.4 inch
N.W.:	2.7KG / 6lbs
Maximum Noise:	74dBA

13

Daily Maintenance

Hose Storage Method

Wrap the hose clockwise around the fuselage, and the hose snaps into the buckle on the side of fuselage to fix it



12

Safety Information

General Warning

- This product only for household use, not for commercial or industrial use, nor for outdoor or humid places;
- Never leave children alone to use or people with weak considering ability;
- Please ensure an environment where it can be used safely, under the instructions and supervision of a person whom understand the safely use of the product and its hazards. Under such circumstances, keep away from children and pets, never leave the product on the place where children and pets can touch and play with.
- Please pay full attention do not touch the plug and product with wet hands. Do not use this product absorb moisture and liquid.
- Please do not use the product while the power cord or power plug is damaged.
- Please do not use the product In case of the product not working normally, damaged or immersed in liquid.Please be sure to contact our company. Please do not disassemble the product,wrong assemble method may cause electric shock or fire.
- Please do not inhale gas or any other flammable liquid, and do not use it under the condition flammable or combustible near by.
- Please do not pull the power cord, do not put heavy objects on the top of the machine. Avoid wire clamped by the door while it closed.
- **Please do not use the machine to inhale burning, smoking, or hot things such as cigarettes, matches, or hot soot**
- Please pull off the plug from the socket after use, maintain the machine or parts replacement.
- Please do not use or keep it in humid places such as outdoor or in the bathroom or in wet environment.
- Please do not use aromatic compounds or anything with fragrance as filter, Such chemicals may cause the fire.
- Please use the machine under correct voltage, you can found correct voltage on the bottom of the machine.

01

Safety Information


Cautions

- **Please do not operate or unplug the power cord with wet hands.**
- In order to avoid malfunction and electric shock, please absolutely prohibit.
- **Please do not use it in the place where flammable, avoid on fire or may cause bomb.**
- Please do not use it near flammable liquid or anything flammable.
- **There may be a peculiar smell when used for the first time,but it will not cause effects on the body.**
- There will be an odor when use the product for the first time, but it will disappear after a while. Please kindly understand.However, if there have burnt smell persists, please stop using it immediately.
- **Please keep the dust cup and filter clean after use.**
- It may cause malfunction if the dust cup and filter getting dirty, and unexpected accidents may occur.
- **Please make sure the power off and unplug the power cord before proceeding with maintaining.**
- It will be danger of electric shock if turn on the power while maintaining, or cause the accidents and injuries.
- **Please stop using the machine when the temperature rises abnormally.**
- If abnormal heating of the motor occurs or the suction part is blocked, the operation will be stopped immediately, please take out the dust cup, confirm the suction part and filter are clean, and turn on it after 60 minutes.
- **Please ensure all the filter installed well before using.**
- Please be sure the filter installed correctly, motor can be damaged if the filter was removed.

02

Daily Maintenance


Clean the Sponge Filter



1.Please ensure power off, then remove the dust cup and take out the sponge.



2.Washing it in cold water and drain the water.



3.Put it in a well-ventilated place for at least 24 hours of drying




4.Please install the Sponge filter back to the original place after it is completely dry.

11

Daily Maintenance


Clean HEPA




1.Please ensure power off, then remove the dust cup and take out the HEPA.



2.Washing it in cold water and drain the water.




3.Put it in a well-ventilated place for at least 24 hours of drying.



4.Please install the HEPA back to the original place after it is completely dry.

10


Packing List



03


Instruction For Use

Connected the accessories to the vacuum through the Hose




Take the hose from back side of the tray, in the direction of arrow symbol, insert one side of the hose to connect to the host, and the another side to match the accessories.

Dust Cup Install



Put the dust cup gently in the direction of the arrow.

Dust Cup Remove



Remove the dust cup on the opening side in the direction of the arrow.

04

Daily Maintenance

Clean the Dust Cup



Step 1: Remove the dust cup on the opening side in the direction of the arrow.
Step 2: Open the lid and push the buckle to open the dust cup to dump out the trash.
Step 3:Install the dust cup in the direction of the arrow.


Note: Please be careful when hanging the dust cup. Ensure the dust cup is dry after cleaned and dumped with trash to avoid that water ingress into the motor to cause electric shock or damage the machine.

Clean the Electric Clippers

- 1.Please retract the removable knife to the bottom with adjustment knob before installing the knife.
- 2.Vacuum/clean debris from the blade and the clipper.
- 3.Drop the lubricant on the blade.



Remove the blade



clipper




09


Introduction use of Accessories

Foot hair clipper and nail grinder conversion

Remove the head by turning it to the right as shown




load downward and turn left to load the tool head as shown




Display board

you can put them on the display board for next use,after finishing




08

Instruction For Use



05


Introduction use of Accessories



Grooming Brush
It can clean the floating hair on pets and the garbage in the hair.At the same time it has the function of lengthen the hair, making the hair more fluffy




Roller Brushes
It can clean the hair of pets or remove the hair from clothes




Electric clippers
It can shave your pet's hair and suck it into dust cup to prevent it from falling to the floor or somewhere else.
Note: Please be careful on the soft parts of the pet's skin and do not use excessive force to cause skin scratches



Cleaning Brush
It can clean the hair of pets or remove the hair from clothes




Clipping comb
According to different hair style needs optional choose to use.
Note: The objects are scattered and small, please keep them properly when not in use.



Wind Cover
Used to enhance the suction force of the tyre while trimming hair, and at the same time guide the path of the suction par (optional use)
Note: The objects are scattered and small, please keep them properly when not in use.


06

Introduction use of Accessories



Pet foot clipper


It is suitable for trimming the local position of pet foot hair, ear corner nest and so on. Pay attention to the cutting edge and sharp position when using, do not exert excessive force into skin scratches. Local trimming can be used alone without connecting the host



Nail grinder

Polish and smooth pet nails. Do not hurt the pet skin. When grinding nails, can be used alone without connecting the hostexcessive force into skin scratches. Local trimming can be used alone without connecting the host

Battery installation and replacement introduction



Open the battery cover by following the arrow icon

Install the two batteries as shown and close the cover plate

TYPE AAAA

TYPE AAAA

Battery: 2pcs 1.5V-AA Alkaline dry battery

07